

easyapplication

Tips for Optimum Plate Mounting

Cleaning



Process

All elements should be handled at room temperature – or at least at equal temperatures.



Plate Cleaning

Clean back of new or used plate of dust, grease, or other contamination using a suitable solvent.



Cylinder/Sleeve Cleaning

Clean per manufacturer recommendations and wipe dry with clean cloth.

Mounting



Tape Mounting

Apply the tape in a sweeping motion, line by line. Use a squeegee for best results.




Plate Mounting

Only fix the plate on a narrow area of the tape. Avoid premature contact between plate and tape by using liner material.




Mount plate with rubber roller, at least on the leading and trailing edge. This will give a better bond than just by hand.

Demounting



Plate



Tape

Plate and Tape Demounting

Remove plate first, then remove the tape slowly at a flat angle.